

# EXPLORER PTT Push-To-Talk Unit

## Quick Guide - Group call

The EXPLORER PTT Unit automatically turns on when the ignition key is turned. It is ready for use when the display shows the group name and CONN. When the ignition is switched off, the PTT Unit remains on for some time and then switches off automatically.

Press the PTT button to start transmitting. If somebody is talking already, his name is displayed instead of CONN.

Turn the selector wheel to change the group, then press Enter to accept the new group.

**Emergency call:** Press the Distress button on the back for 5 seconds, then press the PTT button to force a call through to the emergency call number.

Menu	Contents
STAT	Network status for BGAN and cellular networks. Current group. CONN or DISCONN state.
INFO	External loudspeaker on (default) or off. External audio (VHF) on (default) or off. Device name, serial number and software version.
EVENT	Current warnings and errors. If any, a triangle is displayed.

Key	Description
Shift	Shifts between the menus and the items in a menu.
Home	Goes back to the STAT menu.
Replay	Replays the last 30 seconds of the received signal.
Call	Switches between CONN and DISCONN state.
Distress	Forces a call through to the emergency call number. (button on the back)

### External audio ON/OFF (VHF)

1. Press Shift to go to the INFO menu.
2. Press Enter to enter the menu.
3. Turn the selector wheel to highlight ExAudio.
4. Press Enter.
5. Turn the selector wheel to highlight ON or OFF.
6. Press Enter to accept the setting.



### External loudspeaker ON/OFF

1. Press Shift to go to the INFO menu.
2. Press Enter to enter the menu.
3. Turn the selector wheel to highlight ExSpeaker.
4. Press Enter.
5. Turn the selector wheel to highlight ON or OFF.
6. Press Enter to accept the setting.

Change the volume of the PTT Unit and the external loudspeaker by turning the volume control.

### To dim the display

1. Make a short press on the dim button.
2. Turn the selector wheel to dim the display.

### Key lock function

Make a long press on the lock button. Press again to unlock.

### To turn on or off manually

Push the on/off button for 2 seconds.